

# INSTALLATION MANUAL

38151A

**ecolight**




UGR19

80 CRI





50W | LED | 230V | IP20 | Aluminium


Complete with driver



## A INSTALLATION



## B CONNECTION



### Warnings:

1. Make sure that the product is installed properly before connecting to electricity.
2. Do not cover the fitting.
3. Maintenance and installation should only be carried out by a professional electrician.