

INSTALLATION MANUAL

65024TA

ecotrackspot




80 CRI



15x1W | 230V | 50/60Hz | IP20 | Aluminium | Adjustable

AC LED



one
LIGHT

<p>1</p> <p>To mount the track adaptor into the track system, first check that the selector knob A is at OFF position and the adaptor lock B is disengaged.</p>	<p>2</p> <p>When installing the adaptor into the track, ensure that it is orientated correctly.</p>	<p>3</p> <p>Rotate adaptor lock B clockwise 90° to connect the adaptor to the neutral circuit.</p>
<p>4</p> <p>After the track adaptor is inserted, close the security button on the adaptor.</p>	<p>5</p> <p>Rotate selector knob A to the position of desired circuit.</p>	<p>5a</p> <p>Circuit 1: Rotate the knob A 90° clockwise from the starting position OFF, to connect circuit 1.</p>
<p>5b</p> <p>Circuit 2: Rotate the knob A 90° anti-clockwise from the starting position OFF, to connect circuit 2.</p>	<p>5c</p> <p>Circuit 3: Rotate the knob A 180° clockwise from the starting position OFF, to connect circuit 3.</p>	<p>6</p> <p>Adjust the light to the direction you need.</p>

Warnings:

1. Make sure that the product is installed properly before connecting to electricity.
2. Do not cover the fitting.
3. Maintenance and installation should only be carried out by a professional electrician.