

# INSTALLATION MANUAL

65650T

ecotrackspot




80  
CRI



30W | 230V | 50/60Hz | IP20 | Aluminium | Adjustable beam

Complete with driver.



one  
LIGHT

<p><b>1</b></p> <p>To mount the track adaptor into the track system, check that both tabs <b>A</b> &amp; <b>B</b> on the adaptor are in the "open" position and insert into the track.</p>	<p><b>2</b></p> <p>Ensure the track adaptor is inserted with the correct orientation.</p>	<p><b>3</b></p> <p>Rotate tab <b>A</b> clockwise 90° to connect the adaptor to the neutral circuit.</p>
<p><b>4</b></p> <p>Rotate tab <b>B</b> to the desired position circuit.</p>	<p><b>4a</b></p> <p><b>Unconnected:</b> The luminaire is fixed to the track but not connected to any circuit.</p>	<p><b>4b</b></p> <p><b>Circuit 1:</b> To connect to circuit 1, from the starting position, rotate the tab <b>B</b> clockwise 90°.</p>
<p><b>4c</b></p> <p><b>Circuit 2:</b> To connect to circuit 2, from the starting position, rotate the tab <b>B</b> anti-clockwise 90°.</p>	<p><b>4d</b></p> <p><b>Circuit 3:</b> To connect to circuit 3, from the starting position, pull the tab <b>B</b> down and rotate anti-clockwise 90°.</p>	

## Warnings:

1. Make sure that the product is installed properly before connecting to electricity.
2. Do not cover the fitting.
3. Maintenance and installation should only be carried out by a professional electrician.