


## **LECA** snooze

INSTALLATION INSTRUCTIONS | JANUARY 2025








#### **DIMENSIONS**



#### MOUNTING INSTRUCTION

- Remove the mounting base from the fixture by loosening the socket screws.
- 2 Make a hole in the wall according to the prescribed dimensions.
- Optional:
  Install a connection box (not included) at 45°.
  Use a round connection box with a depth of 61mm.
- 4 POWER CONNECTION




Connect the earth cable.



- Mount the mounting base on the wall / to the box with screws (screws are not included).
- 6 Connect the connectors of the fixture and driver.
- 7 Fix the luminaire on the base with the socket screws.
- 8 Push the button to turn the light on/off. Hold the button to dim the light.

# **LECA SNOOZE**

INSTALLATION INSTRUCTIONS | JANUARY 2025





### DISMOUNTING AND RECYCLING INSTRUCTIONS

Light source & driver

- 1 Loosen the socket screws from the fixture to remove it from the mounting base.
- 2 Disconnect the plugs and loosen the wires to remove the driver.
- 3 Pull out the honeycomb and snoot by using a flat tool and remove the lens.
- 4 Unscrew the screws, disconnect the wires and remove the light source.
- 5 Unscrew the cover on the backside to remove the board.



The light source is replaceable by Wever & Ducré or by a professional with explicit authorisation. For more information please contact your local Wever & Ducré customer service point.



The driver can be replaced by the end user.



This luminaire contains a light source with the energy class E.

