


Parts needed to mount the KOPRO-30 extrusion



Extrusion
(A)




End cap (B)



Cover (C)



LED strip (D)



Spring (E)


Tools needed for mounting:

- drill
- screwdriver


NOTE! All LED strips must be connected to a 12 V or 24 V power supply.

IMPORTANT: The manual presents the simplest mounting procedure.
More mounting procedures and related accessories can be found at klusdesign.eu


1. Drill holes in the mounting surface (min. 0 10 mm) to mount the extrusion.




2. Drill holes in the extrusion.



3. Mount the LED strip (D), and slide the spring (E) into the extrusion (A).



4. Connect power, then mount the extrusion in the drilled holes using springs.



5. Insert the cover (C) and the end cap (B).

