



w241 Faro Instructions


1.




2.




3.




4.



5.



6.



Mounting instructions

1. Remove the battery cover.
2. Take the battery out and connect the connectors.
3. Put the battery back in the luminaire and then add the connector with the narrow side down. Attach the battery cover.
4. Once the battery is connected, activate it by charging it once. For optimal performance, charge it to 100%. To charge the battery, connect a cord and adapter (not included).
Indicator light during charging:

	
charging	fully charged (~4 hours)
5. Press the button for the battery level indication.

			
100-97%	97-50%	50-10%	10-0%
6. Rotate the top plate to turn the light on/off and to dim.




This product contains a light source of energy efficiency class D. The light source and control gear are replaceable by Wästberg or by a professional with explicit authorisation. Contact customer service at service@wastberg.com

Our product is specifically designed for indoor use, but it also offers limited outdoor application possibilities. However, it is important to avoid prolonged or extreme weather conditions to ensure the product's longevity and performance. Ambient temperature: 25°C.


w241 Faro

Battery sheet


1.




2.



4.



5.



This device is not suitable for non-rechargeable batteries. Use only the designated Wästberg battery. Fire or explosion may result from use of incorrect battery. Keep batteries out of reach of children.

1.

The battery can be removed and replaced. Only use the designated battery available for purchase from Wästberg. (LiFePo4, 9.6V, 2000mAh)

2.

Charge at least once every six months to maintain the battery performance. If the luminaire is not in use, it must be charged once within 2 years.

The luminaire can be used during the charging process.

3.

Do not disconnect the battery while charging as this might damage the battery or reduce its lifetime.

4.

Do not expose the luminaire to fire or any other heat source.

5.

Do not disassemble the battery.

6.

It's recommended to charge the battery when the indicator light is red.




7.

Battery life span:

Brightness level	100%	50%	25%
Battery life span	~7,5h	~14h	~20h

8.

The luminaire is equipped with an RF module that enables connection to a master dimming device (not included).
Frequency range: 2400-2483.5MHz
RF output power: 7.5dBm



This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Caution: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

To satisfy FCC&IC RF exposure requirements, a separation distance of 20 cm or more should be maintained between the antenna of this device and persons during device operation. To ensure compliance, operations at closer than this distance is not recommended.